

William Kenyon®

P.I. Spun 3 Strand splicing instructions

Step 1

Untwist the individual strands of rope back 12" (30cm) from the end of the rope.




Step 2

"Marry" the six strands, staggering the strands from each end as shown, being careful NOT to match colors (DO NOT PUT RED WITH RED, etc.). Leave approximately 1" (2.5cm) space between twisted ends.



Step 3

When working to the left, the first strand is wrapped towards you, around and under the opposite strand, keeping the lay of the rope as near as possible to that of the strand being wrapped.




Step 4

Repeat with the second strand and its opposite, and the third strand and its opposite. Only ONE wrap should be made on each strand at one time.

Step 5

When working to the right, wrap the strands away from you, around and under their opposite strands.



Step 6

Follow this procedure for six wraps, three to the left and three to the right, giving a light, even pull on each end after each wrap is completed.

Step 7

Remove approximately half of the ends from each strand and continue the procedure for three additional wraps to the left and three to the right. This will taper the splice and is highly recommended.



Step 8

Cut off all strand ends leaving tails of 3/4" - 1" (1.9 - 2.5cm) long.

The strands are in three colors for illustration purposes only.

Your Single Source for Paper Machine Threading®

1.800.371.5010

www.williamkenyon.com

Fax: 1.800.995.3054