

William Kenyon®

VIPER® II

A braided rope engineered for the carrier rope application



- Constructed of Engineered Yarns
- Braid on Braid Construction
 - Impregnated for superior abrasion resistance
 - Heat-set for reduced elongation
- Highly textured for superior grip on the tail
- Maintains a round profile without a core due to our engineered construction method
- Ease of splicing using the standard single braid splice
 - Simplified splicing as opposed to braid with a core
- Available in red, green or yellow
 - Protected by at least one of the following patents: U.S. Pat. No. 7,228,777, U.S. Pat. No. 7,703,371, and CA 2,524,055

William Kenyon®

Your Single Source for Paper Machine Threading®

1.800.371.5010

www.williamkenyon.com

Fax: 1.800.995.3054

VIPER[®] II

braid splicing instructions

The ropes are in different colors for illustration purposes only.

Step 1

Ready to splice – carrier rope ends, Kenbest[®] Fid, William Kenyon[®] safety knife, tape, and marker.



Step 2

Mark both ends at approximately 18" (46cm) and 40" (91cm) from end.



Step 3

Push the basket back, insert one end of the rope, and release (to ensure a tight grip on the rope, compress the basket with your fingers). Insert the point of the fid at the 18" (46cm) mark on the opposite end.



Step 4

Push the fid through the rope and bring it out at the 40" (91cm) mark.



Step 5

To make a proper taper, pull the end through. Insert your William Kenyon[®] "lock back" safety knife at approximately 12" and lift slightly one plait. Cut and remove. Repeat at 10", 8", 6", 4", 3" and 2".



Step 6

The tapered end. Unbraid the plaits and work back into the center of the rope completely.



Step 7 Repeat steps 2-6 for opposite end.



William Kenyon[®]